



# Installation, Operation & Maintenance Instructions

## Manual Handle Spring Return Units

### FOR USE WITH THE FOLLOWING MODELS:

- 03++0\*0 - 1016
- 05++0\*0 - 1016
- 05++0\*0 - 1017
- 07++0\*0 - 1016
- \* \*++0\*0 - 101 \* W



### KEY:

++ will be one of the following:

- 0- = Male Drive
- 3F = Female Drive
- 9- = American Male Drive
- 7F = ANSI Female Drive
- 3S = Serrated Female Drive
- 7S = ANSI Serrated Female Drive

\* will be one of the following:

- 2 = Clockwise Spring Action
- 3 = Anticlockwise Spring Action
- W = Low temperature



### 1. INSTALLATION

- 1.1 Fit unit to bracket/valve with coupling to valve stem (unless a female drive version is used which can be directly connected to valve).
- 1.2 Ensure that coupling (if fitted) can be moved without much effort, such that it does not side load valve stem or manual handle shaft.
- 1.3 Refer to Kinetrol TD111 for recommended screw tightening torques.
- 1.4 Ensure that the handle is fitted in the orientation which allows the safe operation from a stable operating position.
- 1.5 Ensure that the unit is only fitted in suitable explosion proof environments as limited by the approved label contents. (See label below.)
- 1.6 If serrated drive is used – use a Kinetrol insert to ensure drive to valve.

### 2. OPERATION

- 2.1 Operating conditions:
  - Angle of travel 90° (Non Adjustable)
  - Max vibrating conditions: 4g @ 100Hz
  - Ambient temperature range (Standard): -40°C to 80°C
  - " " " (Low temp. W): -54°C to 60°C


- 2.2 Ensure that the handle is operated whilst standing in a stable position.
- 2.3 Rotate handle slowly with a good grip and ensure that there is nothing on the path of an accidentally released lever.
- 2.4 DO NOT allow the handle to be released from the hand grip. Slowly and deliberately rotate the handle against the spring. Note: Releasing the handle whilst in the operating position may damage the device and the operating speed may be beyond statutory recommendations.

### 3. MAINTENANCE


- 3.1 This manual spring handle does not contain user serviceable components, if the unit is faulty it should be disposed of safely and replaced with a new unit or returned to Kinetrol for repair.
- 3.2 If the output torque is too high for application, then some sizes can be re-tensioned. TD126 describes the procedure for safely achieving a change in torque.

#### APPROVED LABELS

##### STANDARD



##### LOW TEMPERATURE



Issue	Signed	Date	<b>KINETROL</b> Trading Estate Farnham Surrey England	Doc. No. TD140
H	T.L.	07/07/20		Page 1 of 1